

### **OSS212L-D5 Quick Guide**

Version 1.00 – 2017.09.15



### Thank you for your purchase of Premio OSS212L-D5 Storage Server System!

**1.** Check the Content of the box. Please confirm that your package contains the following:


package contains the following.			
#	Description	Image / Description	Qty
1	OSS212L-D5	- 4	1
	Enclosure		
2	Motherboard	Tyan S7100GM2NR	1
3	CPU and memory	Intel Skylake and DDR4	Opt.
4	IO Cards		Opt.
5	Heatsink		2
6	2x 2.5" Drive Bay		Opt.
7	Slide Rail Kit + Screws		1 set
8	Power Cable*		2
9	Serial Cable*		1

<sup>\*</sup> Inside the accessories box. Box may consist of screw sets for rail kit or drives. If any items are missing, please contact your reseller or sales rep.


# 2. Get Familiar with the Unit.

OSS212L-D5 is a storage server supporting dual Intel processor and front tray-less 12x 3.5" HDDs, an optional rear 2x 2.5" OS drive and 7x low profile PCle slots in a 2U space. Tyan S7100GM2NR and internal cabling are preinstalled. Other motherboard model, IO cards, CPU, and memory can be preinstalled upon request.


### Front view of the unit



#### Rear view of the unit




# 3. Remove the Top Covers of the unit as follows:



Remove the middle cover to get access to internal fans. The rear cover is for motherboard access.


**4. Inspect the Inside** of the unit. Internal components comprise of a Tyan motherboard, an expander board (to IO cards), an optional rear 2x 2.5" bay, 3x system fan modules and 2x IO card fan modules (all connected to the motherboard).




See two options below to install OS disks.




# **OSS212L-D5 Enclosure Quick Guide**




# **5. Install Motherboard Components** (CPU, heatsink, memory) using the guidelines below. For further details, refer to the motherboard TPS.




### **6.** Remove the Inner Rail from the slide rail.




### 7. Install Inner Rails to the enclosure.




## 8. Install the Outer Rails to the Rack as follows:



To remove slide rails, use the latches to undo the assembly as follows:



# 9. Install the Unit to the Rack as follows:




For a complete instruction on how to install unit to the rack, please follow the Slide Rail Installation Guide.



At least two people are recommended for mounting process.

# **10.** Install **2.5"** Drives to the enclosure as illustrated:



To remove the disk, open the drive bay cover, pull the handle out so that drive slightly slides out, and pull out the drive with hand.

# **11. Drive Mapping** of OSS212L-D5 is as follows:







**12.** Plug in the Power Cords to the AC receptacles on the back of the unit.



**13.** Press the Power Button on the front of the unit and for the system to boot up.



**14.** Access the Serial Console (when necessary) by connecting a serial audio cable to the one of the console ports. Use a terminal console with baud set 38400, 8, N, 1, N. Type "help –a" for a list of commands.



For management through Eth port, refer to unit's User's Guide.