BCO-500-RK3568J Semi-Rugged Fanless Mini Computer with Rockchip ARM Cortex-A55 RK3568J, 1x HDMI, 2x USB, 1x CAN, 2x COM, 2x LAN Getting Started Guide for AWS IoT Greengrass

Table of Contents

1	Document Information	. I
2	Overview	. 2
3	Hardware Description	. 2
4	Set up your Development Environment	. 2
5	Set up your Hardware	. 3
6	Setup your AWS account and Permissions	. 3
7	Create Resources in AWS IoT	. 3
8	Install the AWS Command Line Interface	. 4
9	Install AWS IoT Greengrass	. 4
10	Create a Hello World Component	. 4
11	Troubleshooting	. 5

1 Document Information

Version Date Description
1.0 October 2025 Publish Document

2 Overview

2.1 Introduction

The BCO-500-RK3568J Series is an ARM-based, fanless mini industrial computer purpose-built for edge computing in space-constrained and semi-rugged environments. Powered by the Rockchip RK3568J processor, this compact system balances power efficiency with versatile I/O, wireless expansion, and flexible OS support.

2.2 About AWS IoT Greengrass

To learn more about AWS IoT Greengrass, see how it works and what's new.

3 Hardware Description

3.1 DataSheet

Click on this link (https://premio.blob.core.windows.net/premio/uploads/resource/data-sheet/BCO-500-ROK/DS_BCO-500-RK3568J_Premio.pdf) to view the datasheet of BCO-500-ROK.

3.2 Additional Hardware References

Please refer to the BCO-500-ROK device page for more product details

3.3 User Provided Items

Not applicable.

3.4 3rd Party Purchasable Items

Not applicable.

4 Set up your Development Environment

AWS IoT Greengrass supports both Windows and Linux:

https://docs.aws.amazon.com/greengrass/v2/developerguide/operating-system-feature-support-matrix.html.

Please refer to the developer guide for the required tools and proper setup: https://docs.aws.amazon.com/greengrass/v2/developerguide/what-is-iot-greengrass.html

It is recommended to install the following tools/SDKs:

- Java Runtime Environment (JRE) version 8 or greater
- Java Development Kit (JDK) Amazon Corretto 11
 (https://aws.amazon.com/corretto/) or OpenJDK 11 (https://openjdk.java.net/)
- GNU C Library (https://www.gnu.org/software/libc/); (glibc) version 2.25 or greater

5 Set up your Hardware

Please refer to the device <u>User's Manual</u> for the hardware setup.

6 Setup your AWS account and Permissions

Refer to the online AWS documentation at Set up your AWS Account: https://docs.aws.amazon.com/iot/latest/developerguide/setting-up.html

Follow the steps outlined below to create your account and user to get started:

• Sign up for an AWS account:

https://docs.aws.amazon.com/iot/latest/developerguide/setting-up.html#aws-registration

• Create a user and grant it the proper permissions:

https://docs.aws.amazon.com/iot/latest/developerguide/setting-up.html#create-iam-user

Open the AWS IoT console:

https://docs.aws.amazon.com/iot/latest/developerguide/setting-up.html#iot-console-signin

7 Create Resources in AWS IoT

Refer to the instructions on how to create AWS IoT resource: https://docs.aws.amazon.com/iot/latest/developerguide/create-iot-resources.html

Follow the steps outlined in these sections to provision resources for your device:

- Create an AWS IoT Policy
- Create a thing object

8 Install the AWS Command Line Interface

To install the AWS CLI on your host machine, refer to the instructions: https://docs.aws.amazon.com/cli/latest/userguide/getting-started-install.html

Installing the CLI is required to complete the instructions in this guide. Once you have installed AWS CLI, configure it per the instructions:

https://docs.aws.amazon.com/cli/latest/userguide/cli-configure-quickstart.html#cli-configure-quickstart-config

Set the appropriate values for access key ID, secret access key, and AWS Region based on your AWS account. You can set Output format to "json" if you prefer.

9 Install AWS IoT Greengrass

Follow the online guide to <u>Install with automatic provisioning</u>. Refer to the instructions in the following steps:

Set up the device environment

<u>Provide AWS credentials to the device</u>. For development environments, you can use the option "Use long-term credentials from an IAM User". An example of how to do this is shown below:

export AWS_ACCESS_KEY_ID=<the access key id for your user> export AWS_SECRET_ACCESS_KEY=<the secret access key for your user>

<u>Download the AWS IoT Greengrass Core software</u> Install the AWS IoT Greengrass Core software

10 Create a Hello World Component

In AWS IoT Greengrass v2, components can be created on the edge device and uploaded to the cloud, or vice versa.

To create, deploy, test, update and manage a simple component on your device, follow the instructions under the section "To Create a Hello World Component": https://docs.aws.amazon.com/greengrass/v2/developerguide/getting-started.html

To upload the component to the cloud, follow the instructions under the section "Upload Your Component":

https://docs.aws.amazon.com/greengrass/v2/developerguide/upload-first-component.html

10.1 Deploy your component

Follow the instructions online at <u>Deploy your Component</u> to deploy and verify that your component is running.

11 Troubleshooting

For AWS IoT Greengrass general troubleshooting tips, please refer to: https://docs.aws.amazon.com/greengrass/v2/developerguide/troubleshooting.html

For device specific troubleshooting guide, please contact us directly at techsupport@premioinc.com.