USER'S MANUAL

PI-ZB195P25FH02

Industrial Zero-Bezel Touch Monitor

Table of Contents

		03
Revision		03
Disclaimer		
Copyright I	Copyright Notice	
Trademark	Trademarks Acknowledgment	
Environme	ntal Protection Announcement	03
Safety Precautions		04
Technical Support and Assistance		.05
Conventior	is Used in this Manual	.05
Package Co	intents	05
Ordering Ir	itormation	06
Chapter 1	Product Introductions	07
1.1	Overview	.08
1.2	System I/O	09
	1.2.1 I/O	09
	1.2.2 Cable Management	09
Chapter 2	Packing and Handling	10
2.1	Warning	11
2.2	Package List	11
Chanter 2	Installation and Application	12
Chapter 5		
3.1	VESA Mount Installation	13
3.1 3.2	VESA Mount Installation OSD Function	13 13
3.1 3.2	VESA Mount Installation OSD Function	13 13 14
3.1 3.2	VESA Mount Installation OSD Function 3.2.1 Main Menu 3.2.2 Image	13 13 14 14
3.1 3.2	VESA Mount Installation OSD Function 3.2.1 Main Menu 3.2.2 Image 3.2.3 Color Temp	13 13 14 14 14
3.1 3.2	VESA Mount Installation OSD Function 3.2.1 Main Menu 3.2.2 Image 3.2.3 Color Temp 3.2.4 OSD Setting	13 13 14 14 14 14
3.1 3.2	VESA Mount Installation OSD Function 3.2.1 Main Menu 3.2.2 Image 3.2.3 Color Temp 3.2.4 OSD Setting 3.2.2 Reset	13 13 14 14 14 14 15
3.1 3.2	VESA Mount Installation OSD Function 3.2.1 Main Menu 3.2.2 Image 3.2.3 Color Temp 3.2.4 OSD Setting 3.2.2 Reset 3.2.3 Misc	13 13 14 14 14 14 15 15
3.1 3.2 3.3	VESA Mount Installation OSD Function 3.2.1 Main Menu 3.2.2 Image 3.2.3 Color Temp 3.2.4 OSD Setting 3.2.2 Reset 3.2.3 Misc OSD Key Information	 13 14 14 14 14 15 15 15
3.1 3.2 3.3	VESA Mount Installation OSD Function	 13 14 14 14 14 15 15 15
3.1 3.2 3.3 Chapter 4	VESA Mount Installation OSD Function 3.2.1 Main Menu 3.2.2 Image 3.2.3 Color Temp 3.2.4 OSD Setting 3.2.2 Reset 3.2.3 Misc OSD Key Information 3.3.1 OSD Board	13 13 14 14 14 15 15 15 15 15

Preface

Revision

Revision	Description	Date
1.0	Manual Released	2018/12/04

Disclaimer

All specifications and information in this User's Manual are believed to be accurate and up to date. Premio Inc. does not guarantee that the contents herein are complete, true, accurate or non-misleading. The information in this document is subject to change without notice and does not represent a commitment on the part of Premio Inc.

Premio Inc. disclaims all warranties, express or implied, including, without limitation, those of merchantability, fitness for a particular purpose with respect to contents of this User's Manual. Users must take full responsibility for the application of the product.

Copyright Notice

All rights reserved. No part of this manual may be reproduced or transmitted in any form or by any means, electronic or mechanical, including photocopying, recording, or information storage and retrieval systems, without the prior written permission of Premio Inc. Copyright © 2015 Premio Inc.

Trademarks Acknowledgment

Intel[®], Celeron[®] and Pentium[®] are trademarks of Intel Corporation.

Windows® is registered trademark of Microsoft Corporation.

AMI is trademark of American Megatrend Inc.

IBM, XT, AT, PS/2 and Personal System/2 are trademarks of International Business Machines Corporation All other products and trademarks mentioned in this manual are trademarks of their respective owners.

FCC Notice

This device complies with Part 15 of the FCC Rules. Operation is subject to the following two conditions: (1) This device may not cause harmful interference;

(2) This device must accept any interference received, including interference that may cause undesired operation.

Environmental Protection Announcement

Do not dispose this electronic device into the trash while discarding. Please recycle to minimize pollution and ensure environment protection.



Safety Precautions

Before installing and using the equipment, please read the following precautions:

- Put this equipment on a reliable surface during installation. Dropping it or letting it fall could cause damage.
- The power outlet shall be installed near the equipment and shall be easily accessible.
- Turn off the system power and disconnect the power cord from its source before making any installation. Be sure both the system and the external devices are turned OFF. Sudden surge of power could ruin sensitive components. Make sure the equipment is properly grounded.
- When the power is connected, never open the unit. The unit should be opened only by qualified service personnel.
- Make sure the voltage of the power source is correct before connecting the equipment to the power outlet; only used the power adapter based on the specs, and contact Premio for any questions.
- Disconnect this equipment from the power before cleaning. Do not use liquid or spray detergents for cleaning.
- Avoid the dusty, humidity and temperature extremes.
- Do not place heavy objects on the equipment.
- If the equipment is not used for long time, disconnect it from the power to avoid being damaged by transient over-voltage.
- The storage temperature shall be above 0°C and below 60°C.
- Do not cover the vent on the monitor nor place the power adapter in places heat is hard to dissipate; also do not install inside a vehicle, this may cause malfunction, electric shock, or fire; avoid any water or outdoor application.
- If one of the following situation arises, get the equipment checked be service personnel:
 - The power cord or plug is damaged.
 - Liquid has penetrated into the equipment.
 - The equipment has been exposed to moisture.
 - The equipment does not work well or it cannot work according the user's manual.
 - The equipment has been dropped and damaged.
 - The equipment has obvious signs of breakage.

Technical Support and Assistance

- Visit the Premio Inc website at <u>www.premioinc.com</u> where you can find the latest information about the product.
- 2. Contact your distributor, our technical support team or sales representative for technical support if you need additional assistance. Please have following information ready before you call:
 - Model name and serial number
 - Description of your peripheral attachments
 - Description of your software (operating system, version, application software, etc.)
 - A complete description of the problem
 - The exact wording of any error messages

Conventions Used in this Manual



This indication alerts operators to an operation that, if not strictly observed, may result in severe injury.



This indication alerts operators to an operation that, if not strictly observed, may result in safety hazards to personnel or damage to equipment.



VOT

This indication provides additional information to complete a task easily.

Package Contents

Before installation, please ensure all the items listed in the following table are included in the package.

PI-ZB195P24FH02				
Item	Description	Q'ty		
1	19.5" P-CAP Touchscreen	1		
2	Power Cord	1		
3	Power Adapter	1		
4	VGA Cable	1		
5	USB Cable (Type B)	1		
6	HDMI Cable	1		
7	DVI Cable	1		

Ordering Information

Model No.	Product Description
PI-ZB195P25FH02	19.5" P-CAP Touchscreen with Anti-Glare

Chapter 1

Product Introduction

1.1 Product Overview PI-ZB195P25FH02 Key Features

- 19.5" TFT Full HD 16:9 LCD with Projected Capacitive Touch
- Zero-Bezel True Flat Display
- Anti-Glare Cover-Glass (Optional)
- Slim Design
- VESA Mount 75 x 75 mm and 100 x 100 mm
- Multi-language OSD built-in
- Cable Management Bridge

Hardware Specification

Display

- LCD Size: 19.5" (16:9)
- Resolution: 1920 x 1080 (Full-HD)
- Brightness (cd/m²): 250
- Contrast Ratio: 3000 : 1
- LCD Color: 16.7M
- Viewing Angle (H-V): 178 / 178
- Backlight MTBF: 40000 hrs (To ½ Brightness)
- Response Time: 25 ms

Touch

- 10-Points Projected Capacitive
- I/0
- VGA Input: 1x VGA Input
- DVI-D Input: 1x DVI-D Input
- HDMI Input: 1x HDMI Input
- USB Input: 1x USB Type B
- Audio Input: 1x Audio Input

Other Features

- OSD:
 - Power, Auto, Menu, Up and Down

Environment

- Operating Temp.: 0°C to 40°C
- Storage Temp.: -20°C to 60°C
- Relative Humidity: 10%~90% (non-condensing)

Physical

- Front Panel Construction: Flat Surface
- Dimension: 490.6 (W) x 294.6 (D) x 39.6 (H)mm
- Mounting: VESA Mounting Holes 75 x 75mm, 100 x 100mm



1.2 System I/O and Cable Management

1.2.1 I/O

DC IN

Used to plug a DC power input with terminal block.

DVI-D

This 24-pin port is for PC (Personal Computer) DVI-D digital signal connection.

VGA

Use the rear panel standard 15-pin female VGA This port connects PC audio source by the connector to connect the monitor to the system bundled audio cable. graphics interface.

HDMI

Use the female HDMI connector to connect the monitor to the system graphics interface

USB (Type B) for Touch Panel Connector

Use the USB (Type B) connector to connect the capacitive touch to the system interface.

Audio-in



1.2.2 Cable Management

Cable Management Bridge



Chapter 2

Packing and Handling

2.1 Warning



Premio takes every precaution in testing and packing its products prior to shipment.

On delivery of the products, check the shipping carton for damage. If any damage is seen that could have caused damage to the contents, keep all packing materials for later inspection by Premio or the carrier who are responsible for any shipping damage.

Handle the monitor with care. Take care not to mark or scratch the glass when removing it from its packing.

2.2 Packing List

- 1. 19.5" P-CAP Touch Monitor
- 2. Power Cord
- 3. Power Adapter (110V-240V)
- 4. VGA Cable
- 5. DVI Cable
- 6. HDMI Cable
- 7. USB Type B Touch Cable

Please open the package carefully and check the items in the package; please contact Premio inc. if any items are missing.



Installation and Application

3.1 VESA Mount Installation

The zero-bezel touch monitor uses VESA mounting method.

0 ٥ m 100.00 00000 0 0 0000 0000 0000 0000 0000 900 900 900 900 900 0 0 0 0 0 0 VESA:M4 THREAD MAX:SCREW DEPTH=9mm X8

3.2 OSD Functions

3.2.1 Main Menu

BRIGHTNESS	7
CONTRAST	5
ECO	STANDARD
DCR	◀ OFF ▶
Constant of the second s	

3.2.1 Main Menu

Brightness

Adjust the backlight level; default at 70 (0~100)

Contrast

Adjust the picture contrast; default at 50 (0~50)

Eco

Switch between different contextual model to <Standard>,<Text>,<Game>,<Movie>.

DCR

Turn on the dynamic contrast ratio <on> and <off>.

3.2.2 Image

H. Position Adjust the horizontal position; default at 50 (0~50)

V. Position Adjust the vertical position; default at 50 (0~50)

Adjust picture width; default at 50 (0~50)

Phase Adjust picture focus quality; default at 39 (0~50)

Select image aspect to <4:3> or <Wide>

3.2.3 Color Temp

Color Temp Select the color of the picture mode <warm>,<cool>, and <user>

User

Adjust color by <RED>, <Green>, <BLUE> (0~100)

3.2.4 OSD Setting

Language

Select from following <English>, <Deutsch>, <Chinese>, <Itanliano>, <Francais>, <Korean>, <Espanol>,<Portuge>, <Turkce>, <Polski>, <Nederlands>, <Pyccknn>

H. Position

Adjust the horizontal position of the OSD; default at 50 (0~50)

OSD Timer Adjust the OSD menu timeout; default at 10 (0~100)

Transparency Select the transparency of the OSD; default at 0 (0~100)

3.2.5 Reset

Image Auto Adjust Auto adjust the image

Color Auto Adjust Auto color calibration

Reset to factory setting

3.2.6 Misc

Signal Source Select signal source from <VGA>, <DVI>, or <HDMI>

On or off the audio output

Adjust the audio volume; default at 50 (0~100)

3.3 OSD Key Information

3.3.1 OSD Board



3.3.1 OSD Key Events

LED

Green: Normal operation

Red: No Signal, sleep mode, factory mode, burn-in mode

Off: System off

Power

Turn on or off the system

Auto

Adjust the picture to source the analog input

Exit menu or sub-menu

Menu

Display OSD menu

Select high-lighted function

Keep pressing for 6 seconds, turn OSD LOCKED or UNLOCKED

Up

Select previous item or increase value

Select brightness adjust menu

Down

Select next item or decrease value

Switch signal source

Power + Menu: Combined key, enter factory mode, LED turn red

Chapter 4





Warranty

Premio is only under obligation to offer the following Warranty Repair and Services except those authorized formal documents in written form:

3 Years (Touch screen & LCD panel: 1 year)

The above warranty period takes the front four places of the Serial Number label on Premio products as the starting date. Warranty products cover panel, controller and communication cable. Accessories included with the products are not included in the warranty

Chapter 5

Troubleshooting



Connectivity

- The signal cable should be fully connected to the graphics card/computer.
- The graphics card should be completely seated in its PC slot.
- Power Button and computer power switch should be in the ON position.
- Check to make sure that a supported mode has been selected on the graphics card or system being used. (Please consult graphics card or system manual to change graphics mode).
- Check the monitor and your graphics card with respect to compatibility and recommended settings.
- Check the signal cable connector for bent or pushed-in pins.
- Check that the BNC or D-SUB button is in the correct position.



Power Button

• In case when power button does not respond, unplug the power cord of the monitor from the AC outlet to turn off and reset the monitor, or simultaneously press the RESET and Power buttons.



Image

- Signal cable should be fully connected to the computer.
- Use the OSM[™] Image Adjust controls to focus and adjust display by increasing or decreasing the Fine control.
- When the display mode is changed, the OSM Image Adjust settings may need to be re-adjusted.
- Check the monitor and your graphics card with respect to compatibility and recommended signal timings.
- If your text is garbled, change the video mode to non-interlace and use 60Hz refresh rate.



Monitor

- In case of monitor not lit, make sure power button should be in the ON position and power lead should be connected. Make certain the computer is not in a power-saving mode (touch the keyboard or mouse if present).
- In case of image not correctly sized, use the OSM Image Adjust controls to increase or decrease the H. Size. Check to make sure that a supported mode and signal timing has been selected on the graphics card or system being used (Please consult the graphics card or system manual to change graphics mode or refresh rate).
- In case of selected resolution is not display properly, Select the Display Resolution in the OSM Information menu to confirm that the appropriate resolution has been selected. If not, select corresponding option by pressing the control button.

1	~	
L	1	

No Touch

 Check that the software driver is correctly installed. Or, try to uninstall the driver first, and then reinstall the driver and reboot the computer. If there is no problem about the software driver, Please replace the Digitizer Pen to have a try. If the problem persists, please contact our technical support engineer.

Copyright © Premio Inc. All Rights Reserved **www.premioinc.com**